TOP AND CONSOLE PARTS

29" GAS DRYER

For Models: GGW9878PW1, GGW9878PG1
(White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: GGW9878PW1, GGW9878PG1
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8562582	Installation Instructions
	8533771	Sheet, Cycle Feature
	8578183	Use & Care Guide
	8533776	Tech Sheet
	8535825	Sheet, Feature Resource Saver

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

	677818	Dryer
2	3405281	Power Relay (2)
3	3976623	Control Board
4		Cap, End (L.H.)
	8271365	White
	8271368	Biscuit
5	717252	Plug, 2−Way Terminal
6	8274261	Panel, Rear Console
7	3405152	Switch, Wrinkle Shield
8		Cap, End (R.H.)
	8271359	White
	8271362	Biscuit
9	693995	Screw, Hex Washer Head
10		Screen, Lint
	8557857	White
	8557858	Biscuit
11	8536939	Clip, Spring
12	237446	Washer (Top/Chute)
13	688983	Screw, 8−18 x 5/8
14	8533951	Screw, Grounding
15	3395683	Connector (Motor)
16		Top
	8557927	White
	8557928	Biscuit
17	343641	Screw, 10−16 x 1/2
18		Knob, Control (3)
	8544937	Silver
	8544938	Biscuit
19	3394427	Clip−Harness
20	388326	Screw, Console
21	8299771	Timer Assembly (60 Hz.)
22	8283281	Harness, Console
23	3388228	Screw, 6−20 x 3/8
24	3397269	Connector−Timer
25		Knob, Push−To−Start
	8544941	Silver
	8544942	Biscuit
26	3403499	Connector, 2−Position (Gas Valve)
27	3403498	Connector, 3−Position (Gas Valve)
28	3936150	Connector, 7−Circuit
29	8533971	Screw, 8−18 x 5/16
30	357213	Nut, Push−In (2)
31	8299900	Harness, Wiring
32	8299970	Switch, Temperature
33	3347243	Connector 6−Circuit
34	3405151	Switch, Signal
35	8533990	Medallion
37	3977456	Switch, Push−To−Start
38		Timer Knob Assembly
	8544957	Silver
	8544958	Biscuit
39	94614	Terminal, Female
40	8544895	Bracket, Control
41		Panel, Control (Includes Illus. 35)
	8545982	Silver
	8545984	Gold
42	3936144	Connector

CABINET PARTS

For Models: GGW9878PW1, GGW9878PG1
(White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GGW9878PW1, GGW9878PG1
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10−32 x 5/8 (External Ground)
2	343641	Screw, 10−16 x 1/2
3	693995	Screw, Hex Head
4	8541400	Bracket, Cabinet
5	3396795	Cover, Block
6	3404162	Clamp, Motor (W/Shield)
7	3396805	Panel, Rear
8	8546676	Clip, Door Spring
9	98669	Locator, Top
10	3406107	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
12	18849	Pad, Top Hinge
13	3357011	Screw, 10−16 x 1/2
14	8541401	Spring, Door (2)
15	3980175	Clamp−Elbow
16	3392100	Foot, Dryer
	279810	Foot−Optional (Extended Length) (Package of 2) (Not Included.)
17	342043	Screw, 10−32 x 3/8
18		Cabinet (Includes Illus. 4)
	8530603	White
	8530606	Biscuit
19	98234	Clip, Ground (2)
20	18776	Lock, Front Top (2)
21		Panel Front
	3395197	White
	3977243	Biscuit
23	685203	Clip, Felt Pad (2)
24	3389441	Catch, Door Assembly
25	3390731	Seal, Door
26	337189	Clip, Hinge (2)
27	694091	Screw, 8−18 x 3/8
28	8066056	Hinge, R.H.
	8066057	Hinge, L.H.
29	696144	Strike, Panel
30	695737	Door, Rear
31		Door, Front
	3393549	White
	3977241	Biscuit
32		Handle, Door
	690270	White
	3977242	Biscuit
33	3406129	Seal & Bearing Assembly
34		Plug, Front Panel
	3394975	White
	3394978	Biscuit
35	344020	Cord, Power
36	3394083	Clip, Front Panel (2)
37	238088	Hinge, Top (2)
38	691366	Idler & Pulley Assembly
39	8066065	Belt, Drive
40	348780	Base, Motor
41	3400500	Bolt, 5/16−18 x 3/4
42	3394341	Pulley, 60 Hz.
43	8066206	Motor Assembly 60 Hz.
44	660658	Clamp, Motor
48	8318272	Burner Assembly, 60 Hz. (See Pages 7 & 8 For Further Burner Breakdown)
49	341029	Clamp, Pipe

BULKHEAD PARTS

For Models: GGW9878PW1, GGW9878PG1
(White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GGW9878PW1, GGW9878PG1
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8−18 x 5/8
3	3388703	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8−18 x 3/8
6	487909	Screw, 8−15 x 1/2
7	3390719	Fuse, Thermal
8	8066086	Drum Hole Plug
9	3976615	Thermistor
10	694089	Wheel, Blower (Includes Illus. 21)
11	8577231	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	8530285	Box, Heater
15	3403140	Thermostat, 205°F (96°C)
16	280010	Kit, Thermal Cut−Off (Includes Illus. 15)
17	3401707	Wire, Jumper
18	8066049	Funnel, Burner
19	3403634	Socket Assembly
20	3406124	Bulb
22	3977373	Bracket, Drum Light
23	3406022	Bracket, Bulkhead
24	3976479	Pad, Sensor
25	690997	Ring, Tri
26	3399506	Shaft, L.H.
27	3399507	Shaft, R.H.
28	3397590	Roller, Support
29	348197	Washer, Support
30	3359452	Nut, 3/8−16
31	3403414	Bulkhead
32	338906	Sensor, Radiant
33	3402841	Lens, Drum Light
34	692526	Ring, Bearing
35	97787	Screw, 11−16 x 3/4
36	3406130	Seal, Rear Drum
37	695587	Drum Assembly
38	692490	Baffle, Drum (2)
39	3976434	Bracket, Support
40	90296	Clip
41	3403636	Baffle, Drum (1)
42	339956	Seal
43	696302	Shield, Exhaust
44	3390647	Screw, 8−18 x 1/2

8318272 BURNER ASSEMBLY

For Models: GGW9878PW1, GGW9878PG1
(White/Grey) (Biscuit/Gold)

USE WITH TYPE 1 − NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8318272 BURNER ASSEMBLY

For Models: GGW9878PW1, GGW9878PG1
(White/Grey) (Biscuit/Gold)

USE WITH TYPE 1 − NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8318272	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8−32 x 5/8)
6	343641	Screw, 10−16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8−18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318277	Valve, 60 Hz. (Includes Pipe & Illus. #7)
11	694421	Screw, 8−32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572	Conversion Kit (Type 1) to Type (4) L.P.G.

BA−150

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: GGW9878PW1, GGW9878PG1
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
		ACCESSORY PARTS
	279948	Kit, Dryer Repair
	346764	Kit, Hold−Down (Gas Dryer Mobile Home Installation)
	3406839	Dry Rack
	8522199	Kit, Dryer Vent Testing
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4392899	Biscuit
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	4392901	Biscuit
	350938	Primer, Gray
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit(Uncut)